

SHUMBIT.

# 0445110181 Injector CRI1-13Technical File

SKU1: G1W20445110181

SKU2: G1S80445110181











# 0445110181 Injector CRI1-13 Technical File

# Content

1.0445110181 Injector's Introduction	2
1.1. 0445110181 Injector's Basic Information	2
1.2. 0445110181 Injector's Common Part Number	2
1.3.0445110181 Injector's Matching Information	3
1.3.0445110181 Injector's Matching Information	93
1.5.0445110181 Injector's Specifications and Dimensions	4
1.6. 0445110181 Injector's Quality Control	4
1.7. 0445110181 Injector's Customized Service	
1.8.0445110181 Injector's Packing List and Package Size	5
1.9.0445110181 Injector's Testing Standard and Certificate	е
1.10.0445110181 Injector's Warranty Instructions	6
1.11.0445110181 Injector's Manufacturer	7
2.0445110181 Injector Technical Support	7
2.1.0445110181 Injector's Part Number Location	7
2.1.0445110181 Injector's Part Number Location	8
2.3.0445110181 Injector's Installation	8
2.4. 0445110181 Injector 's Reasons for Not Working Normally	<u>c</u>
2.5. 0445110181 Injector 's Causes of Damage	9
2.6.0445110181 Injector's Technical Support Obtaining Methods	. 10
3.0445110181 Injector's Purchase and Delivery	10
3.1.0445110181 Injector's Purchase Payment Term	. 10
3.2.0445110181 Injector's Main Sales Markets	10
3.3.0445110181 Injector's Declaration Requirements	10
3.4.0445110181 Injector's Shipping Ways	. 10
3.5.0445110181 Injector's Lead time	10
3.6.0445110181 Injector's Logistics Time for Destination Out of China's Areas	
3.7.0445110181 Injector's Packing	. 11
	12
4.0445110181 Injector's Storage Standard	. 13
5.1. Company Introduction	13
5.2. Sales-men's Contact Information	. 14
6. Copyright Statement	. 14
	-Caro
THE	
Storm	98
AND	38
54. 54. 54. 54. 54. 54. 54. 54. 54. 54.	Secur
CONTROL STATES	

Mob/WhatsApp: +86 13410541523 Email: ruby@shumatt.com

© 2022 Shenzhen Shumatt Technology Co., Ltd

Website: www.shumatt.com

Tel: +8675523215133



# 0445110181 Injector CRI1-13 Technical File

# 1.0445110181 Injector's Introduction

### 1.1. 0445110181 Injector's Basic Information

Title	China made new high quality diesel injector 0445110181 fuel injector CRI1-13
SKU 1	G1W20445110181
SKU 2	G1S80445110181

### 1.2. 0445110181 Injector's Common Part Number

# (1) Injector's Exchange Information

Injector Part Number	Re-manufactured Part Number
0445110181	0 986 435 053
0445110182	The Party Carlotte Street, Str.

# (2) Injector's Application Information

Injector Part Number	MERCEDES-BENZ Car Model	DODGE	FREIGHTLINER	
A A	612 070 04 87	al al a	1 31 31	25 25
044E440403	A 612 070 04 87	and the state of t	Shifter Shifter Sh	Shrigan Sh
0445110182	612 070 03 87			
	A 612 070 03 87			
	612 070 04 87	R5135154AB	R5135154AB	
THE PERSON NAMED IN	A 612 070 04 87	Maria California California	THE PERSON NAMED IN	CONTENT OF THE PARTY OF
0445110181	R5135154AB	an an	311. 311. 311.	300,
May May	612 070 03 87	Fire Princ Princ	Mary Mary P	Mary Mary
athir athir at	A 612 070 03 87	all sign	Stranger Stranger	
25 25	612 070 04 87	05135 154AA	R5135154AB	
str <sub>iller</sub> , str <sub>iller</sub> , st	R5135154AB	R5135154AB	Shripe. Shripe. Sh	an anger an
	612 070 04 87 0080	5135 154AA		
	A 612 070 04 87 80	SELL , THE DEEL , THE RESEL	AND THE STREET	
91 91 91	612 070 04 87 80	40.0	51 51 51	501 501
0 986 435 053	A 612 070 03 87	STATE STATE	THE THE PARTY OF	OFT STATE OF
su. su si	A 612 070 04 87 0080	31, 31,	sm sm sm	\$50.
SHARKE SHARKE	A 612 070 03 87 80	Mr. Mr. Mr.	Mar Mar M	anti anti
	A 612 070 04 87	algu. algu.	3 m 3 m 34	n. 3/gr., 3/g
-03 -03	612 070 03 87	and and a	5 -05 -05	-65 -65
support support	612 070 03 87 80	ac. Storac. Storac.	Styles Styles Sty	ger site and

### (3) Injector's Part Number Common Writing

0445110182, 0445110181, 0986435053, 0 445 110 182, 0 445 110 181, 0 986 435 053, 0 445 110182, 0 445 110181, 0 986 435053, 0 445110182, 0 445110181, 0 986435053, 0445 110 182, 0445 110 181, 0986 435 053, 0445110 182, 0445110 181, 0986435 053,

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



400

-60%

0445 110182, 0445 110181, 0986 435053, 612 070 04 87, 6120700487, 612 070 04 87 0080, 61207004870080, 612 070 04 87 80, 612070048780, A 612 070 04 87 0080, A61207004870080, A 612 070 04 87, A6120700487, 612 070 03 87 80, 612070038780, R5135154AB, A 612 070 04 87 80, A612070048780, A 612 070 03 87, A6120700387, A 612 070 03 87 80, A612070038780, 612 070

### **1.3.**0445110181 Injector's Matching Information

		ctor 5 Mat									
Vehicle brand	Series	Car Model	Engine Model	Production date	Power KW	emission standard	Horse power	Manufacturer	Emission	Cylinder	Power Source (V)
MERCEDES -BENZ	Accelo	715 C (Accelo)	612.983	2003/03 - 2005/12	115	156			2.7	5	12
MERCEDES -BENZ	Accelo	715 C (Accelo)	OM 612 LA	2003/03 - 2005/12	115	156			2.7	5	12
MERCEDES -BENZ	Sprinte r	311 CDI Sprinter	OM 611 LA	2001/06 - 2004/12	80	109		MERCEDES -BENZ	2.2	4	12
MERCEDES -BENZ	Sprinte r	313 CDI Sprinter	OM 611 LA	2011/06 - 2012/05	95	129		MERCEDES -BENZ	2.2	4	12
MERCEDES -BENZ	Accelo	715 C (Accelo)	612.983	2003/03 - 2005/12	115	156			2.7	5	12
MERCEDES -BENZ	Accelo	715 C (Accelo)	OM 612 LA	2003/03 - 2005/12	115	156			2.7	5	12
MERCEDES -BENZ	Sprinte r	311 CDI Sprinter	OM 611 LA	2001/06 - 2004/12	80	109			2.2	4	12
MERCEDES -BENZ	Sprinte r	313 CDI Sprinter	OM 611 LA	2001/06 - 2012/05	95	129			2.2	4	12
MERCEDES -BENZ	Sprinte r	413 CDI Sprinter	OM 611 LA	2001/06 - 2012/05	95	129			2.2	4	12

# 1.4.0445110181 Injector's Parameter

Adaptation System: Common Rail System

Injector Series: 110 Series

Parameter Performance: CRI1-13

Matching Accessories: 1987 972 076, gaske t

Injector Type: Electromagnetic Injector
Support System Maximum Pressure: 1350

Vehicle Configuration Information: MERCEDES-BENZ/DODGE/FREIGHTLINER

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



# 1.5.0445110181 Injector's Specifications and Dimensions

Injector Size: 21.5cm\*4 cm \*4 cm = 344cm3 (L\*W\*H=V)

Injector Net Weight: 0.55kg

Gross Weight: 0.6kg

Injector Quality: China Made Brand New

Package Size: 28cm\*7 cm \*7 cm = 1372 cm³

Injector Type: Diesel Common Rail Injector

MOQ: 4 Pieces

#### 1.6. 0445110181 Injector's Quality Control

## (1) Injector Testing

All injector spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

#### (2) Injector Assembling

And the quality control of the injector production and installation process, our company strictly follows the standard product installation data and product installation steps to install, such as injector stroke test, injector solenoid valve tightening torque, injector nozzle tightening torque,

#### (3) Injector Inspection

-00 P

The factory inspection of the injector is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same fuel injector for a total of no less than three times for factory inspection, and the fuel injector installation testing environment are progressed in dust-free workshop.

# 1.7. 0445110181 Injector's Customized Service

(1) Injector's Customized Service: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, injector internal packaging, injector external packaging and labels customized, etc.



#### (2) Injector's Customized Service Requirements:

The purchased of customized injector are not less than 10 pieces.

Customized injector packages no less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

▲ Once the customized fuel injector is sold, it cannot be returned or exchanged if there is no quality problems.

Trigge Trigge

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



# Shenzhen Shumatt Technology Co., Ltd

## 1.8.0445110181 Injector's Packing List and Package Size

### (1) Injector Spare Parts List

Standard of the sealing performance between the injector and the engine   Solenoid Valve Protective Cape and the engine	Control Control	* Deb* Deb* Sed.* Sed.* Sed.*	2 (2 (2 (2 (2 (2 (2 (2 (2 (2 (2 (2 (2 (2	Test 1 Dest 2 Dest 1
Name  Puel Injector  Ensure to meet the standard of the sealing performance between the injector and the engine  No.  No.  No.  No.  No.  No.  No.  No	No.	1	2	3
Description   Fuel injector part number: 0445110181   Ensure to meet the standard of the sealing performance between the injector and the engine	Image	Shema		est
Fuel injector part number: 0445110181  Standard of the sealing performance between the injector and the engine  No. 4 5 6  Image  Nozzle Protective Cover Cap  Protect nozzle holes from being polluted and blocked  No. 7 8 9  Image  Name  VCI Anti-rust Bag  Name  VCI Anti-rust Bag  Prevent fuel injector from  Prevent the injector from being place injector and injector and injector place injector and injector from being place injector and injector and injector place injector and injector place injector and injector place injector and injector place injector and injector from being place injector and injector place injector and injector from being place injector and injector and injector place	Name	Fuel Injector	O-Ring	Gasket F 00V C17 503
Name	Description	and the second control of the second control	standard of the sealing performance between the injector	Made of brass, used to ensure the tight fit between the injector cap end
Name  Nozzle Protective Cover Cap  Protect nozzle holes from being polluted and blocked  No.  No.  No.  No.  No.  No.  No.  No	No.	4	5	6
Name  Nozzle Protective Cover Cap  Protect nozzle holes from being polluted and blocked  No.  No.  No.  No.  No.  No.  No.  No	Shripper Shripp	in the state of th	Ser.	SHAN SH
Protect nozzle holes from being polluted and blocked   Protect oil inlet from being polluted and blocked   Protect the solenoid valve body and terminals from being damaged by external forces	image المراجعة المراجعة الم		STT STT	77
Protect not not not not not not not not not no	Name	Nozzle Protective Cover Cap	Injector House Protective Cover Cap	Solenoid Valve Protective Cap
Name  VCI Anti-rust Bag  Bubble Bag  Injector Packing Box  Prevent fuel injector from  Prevent the injector from being  Place injector and injector	Description	A Programme of the control of the co	DOUBLE STORY OF THE STORY OF TH	_ mrs _ ross
Name  VCI Anti-rust Bag  Bubble Bag  Injector Packing Box  Prevent fuel injector from  Prevent the injector from being  Place injector and injector	No.	7	8	9
Prevent fuel injector from Prevent the injector from being Place injector and injector	Image			S1 <sup>0</sup>
Prevent fuel injector from Prevent the injector from being Place injector and injector	State, State,	8	W-1 011	\$800 m 200
Prevent fuel injector from Prevent the injector from being Place injector and injector	Name	VCI Anti-rust Bag	Bubble Bag	Injector Packing Box
rusting damaged by external forces accessories	Description	Prevent fuel injector from rusting	Prevent the injector from being damaged by external forces	

A Minors are forbidden to use the fuel injector assembly, O-ring, gasket, nozzle protective cover, fuel injector house protective cover, solenoid valve protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.

▲ O-ring and gasket are disposable installation accessories, and need to be replaced for re-installation.

▲ The nozzle protective cover, the injector house protective cover, and the solenoid valve protective cover are recyclable accessories that can be reused.

▲ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

▲ The injector and the installation parts should be coated with appropriate sealing oil during installation.

# (2) Injector Box Size

Mob/WhatsApp: +86 13410541523 Email: ruby@shumatt.com


© 2022 Shenzhen Shumatt Technology Co., Ltd

5 / 14

Tel: +8675523215133

Website: www.shumatt.com





No.	Name	Injector Package Size (cm)					
. 1° 1	Injector Box	28*7*7					

### 1.9.0445110181 Injector's Testing Standard and Certificate

We can provide the factory quality inspection test report of each injector to ensure that each injector delivered meets the engine performance indicators.



# 1.10.0445110181 Injector's Warranty Instructions

# (1) . Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the injector inspection equipment when the injector is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

#### (2) . Injector Warranty Coverage

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com

© 2022 Shenzhen Shumatt Technology Co., Ltd

Website: www.shumatt.com



Within 15 days after customer receives the 0445110181 injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 0445110181 injector has performance problems during the warranty period (3 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

▲ Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

#### (3) . Injector Out of Warranty Coverage

The warranty period has expired.

Injector failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.

Customer disassembles or repairs the injector personally resulting in damage to the injector.

Injector damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire). Injector failure or injector damage caused by non-injector design, technology, manufacturing, quality and other issues.

Injector failure due to system pressure exceeding system approved pressure.

Injector failure caused by system voltage exceeding approved voltage.

Injector failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.

Injector failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

Injector failure caused by not following the installation angle specified in the vehicle engine maintenance manual.

Injector failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.

Injector failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.

Injector failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.

Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the fuel injector connection in accordance with the fuel intake system specified in the vehicle engine maintenance

### 1.11.0445110181 Injector's Manufacturer

Injector's manufacturer: Shenzhen Shumatt Technology Co., Ltd

# 2.0445110181 Injector Technical Support gris C


order Ch


#### 2.1.0445110181 Injector's Part Number Location

1) E.g.: The injector part number see as follows

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com






	No.	Name
0	\$ <b>A</b> \$	brand, logo, part number, series number
	B_n	nozzle part number

## 2.2.0445110181 Injector's Application Scenarios

Common rail system is an oil supply method refers to the diesel oil from the fuel tank sucked out by the gear pump through the oil-water separator and the gear pump to diesel fine filter, high-pressure pump, common rail pipe, and fuel injector, all together with the closed-loop fuel supply system composed of sensors and ECU that completely separates the generation of injection pressure and the injection process from each other.



Pic No. 1

No.	Name	No.	Name	No.	Name	No.	Name
1	Tank	5	Common Rail Pressure Sensor	9	Engine Crankshaft Sensor	Ą	High Pressure Oil Circuit
2	Diesel Filter	6	Common Rail Pipe	10	Camshaft Sensor	B ST	Low Pressure Oil Circuit
3	High-Pressure Pump	(° 7	Injector	11	ECU Electronic Control Unit	17 Page	There There
4	Fuel Gear Pump	- 8	Accelerator Pedal	ST. The	Sign, Sign, Sign	e e	

### 2.3.0445110181 Injector's Installation

#### (1) .0445110181 Injector's Installation Precautions:

▲ The replacement of the fuel injector must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual,

A Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector, the fitting clearance of the fuel injector connection, the installation angle and tightening torque of the injector, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the injector.

▲ When installing the fuel injector on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the fuel injector, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>



- ▲ Before installing, check whether the fuel injector nozzle gasket has been replaced and installed on the fuel injector.
- When installing the fuel injector, apply lubricant between the fuel injector, fuel nozzle sealing gasket and O-ring.
- ▲ Without replacing new gasket can lead to: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the fuel injector and nozzle to break and cause damage to the engine.
- ▲ When installing the injector on the engine, please carefully check the components related to the installation of the injector, such as the injector pressure plate, screw, injector rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.
- ▲ It is forbidden to operate the bare injector for a long time in an environment with serious dust pollution and corrosion to iron products.
- ▲ It is forbidden to operate the bare injector for a long time in a strong magnetic field environment.

#### 2.4. 0445110181 Injector 's Reasons for Not Working Normally

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle oil pump oil supply system is not normal.
- (3) Engine common rail system oil leakage or pressure limiting valve damage.

ONT THE THE THE THE THE THE

- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the fuel injector of the vehicle.
- (5) The long-term placement of the injector causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.
- A Before installing, carefully check whether other components in the common rail system except the fuel injector are damaged so as to prevent the fuel injector from not working properly after being replaced.

- April - Apri

#### **2.5.** 0445110181 Injector 's Causes of Damage

- (1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the injector .
- (2) The fuel oil used for the vehicle does not meet the standard cause damage to the injector, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the injector.
- (4) The abrasion of the oil pump produces iron powder and aluminum powder enter the fuel injector and cause damage to the fuel injector.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the fuel injector and causing damage to the fuel injector.
- (6) The fuel injector is damaged due to replacement or adjustment of the relevant parts of the fuel injector. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the injector fails to meet the original standard.
  - (7) The engine is overheated and overloaded for a long time working results in damage to the fuel injector.

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



- (8) The injector will be damaged naturally at the end of its working life.
- (9) The injector is magnetized (injector parts' magnetic exceeded) causing the injector to not work properly.

A Before replacing the fuel injector, please check the engine parts carefully according to the engine maintenance manual to avoid the fuel injector being damaged again after replacement.

#### 2.6.0445110181 Injector's Technical Support Obtaining Methods

- (1) Injector Technical File, visit <a href="http://shumatt.com">http://shumatt.com</a> to get the technical file.
- (2) Injector Technical Videos

**Facebook:** Visit <a href="https://www.facebook.com/hison.li">https://www.facebook.com/hison.li</a> to get the technical videos, constantly follow can get more information.

**YouTube:** <a href="https://www.youtube.com/channel/UCByvYBx7VjV">https://www.youtube.com/channel/UCByvYBx7VjV</a> mAfxh Hu-aw to get the technical videos, constantly follow can get more information.

**Shumatt:** Visit <a href="http://shumatt.com">http://shumatt.com</a> to get the technical videos.

(3) Injector Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <a href="http://shumatt.com">http://shumatt.com</a> to get the download and installation tutorial

(4) Search The fuel injector test data through TruckBook Parts EPC APP.

#### 3.0445110181 Injector's Purchase and Delivery

### 3.1.0445110181 Injector's Purchase Payment Term

**Payment Terms:** T/T, PayPal, Alipay, WeChat

Please **c**ontact our salesmen for specific payment information.

#### 3.2.0445110181 Injector's Main Sales Markets

Injector main sales markets: Asia, Europe, North America, South America, Africa etc.

### 3.3.0445110181 Injector's Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

# 3.4.0445110181 Injector's Shipping Ways

**Destination in China areas:** SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

**Destinations out of China's areas:** DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

#### 3.5.0445110181 Injector's Lead time

**Lead time:** Send out within 3-7 working days after receiving payment (Except for special products and special cases).

# 3.6.0445110181 Injector's Logistics Time for Destination Out of China's Areas DHL Logistics Time:

"The The The The The The

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

THE THE THE



# Shenzhen Shumatt Technology Co., Ltd

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK.	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	31. 31. 3	p. 240	30., 30., 30.	34. 34

The logistics time is for reference only, subjects are according to the actual arrival. 57,4700

#### **3.7.0445110181 Injector's Packing**

**Domestic express packaging:** Usually wrapped in waterproof scotch tape, such as picture No.2.

International express packaging: Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 3.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 4, also, the products can be packaged according to customers' requirements.

▲ The packing tray is made of plastic and can be recycled.

A Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

▲ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

© 2022 Shenzhen Shumatt Technology Co., Ltd

Email: ruby@shumatt.com Website: www.shumatt.com





Pic No. 2

Domestic express packaging:

Wrapped with Transparent tape



Pic No. 3

International express packaging:

Wrapped with yellow tape after wrapping black protective film



Pic No. 4

**Pallet Shipping:** Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

# 4.0445110181 Injector's Storage Standard

# (1) Choose a suitable storage place

المراكزية : "المراكزية " المراكزية المراكزية المراكزية المراكزية المراكزية المراكزية المراكزية المراكزية المرا

The warehouse and cargo yard where the fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

# (2) Strict requirements of warehousing

Strict inspections should be carried out when the fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do antirust treatment in time. Packaged injectors must be protected from damage.

# (3) Keep the warehouse dry and preventing moisture

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

The relative humidity is usually below 70% for the fuel injectors placed in the room, and the corrosion of the fuel injectors is significantly reduced.

Injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

### (4) Stack Properly

After the injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

- ▲ It is forbidden to leave the injector exposed in the air for a long time.
  - ▲ It is forbidden to store acid, alkali, salt and other substances together with the injector.
  - ▲ The unpacked fuel injector must be rust-proof during secondary storage.

### 5. Company Information



# 5.1. Company Introduction

Chinese Name: 深圳市舒马特科技有限公司

English Name: Shenzhen Shumatt Technology Co., Ltd

Mob Phone/WeChat: +86-13410541523

☐ HK Telephone: +852-67653519

Telephone: +86-755-23215133

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



Email: ruby@shumatt.com

**Website:** www.shumatt.net

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Room 428-430, Building B, Huafeng Zhigu Technology Industrial Park, Exit B, Fuyong Metro Station, Bao'an District, Shenzhen, China's Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: 1.10.0445110181 Injector Warranty Instructions )

# 5.2. Sales-men's Contact Information

No.	Name	WeChat/WhatsApp	Email	Facebook	YouTube				
1	Ruby	+86-13410541523	86-13410541523 ruby@shumatt.com		Hison Li				
2	lvy	+86-18025299821	sales@shumatt.com	Ivy Shumatt	Shumatt IVY				
3	Rebecca	+86-18025349821	sales01@shumatt.com	Rebecca SHUMATT	SHUMATT Rebecca				
4	Janny	+86-18028749821	sales02@shumatt.com	Janny shumatt	Janny Shumatt				
5	Sam	+86-13316859821	Sales8@shumatt.com	Shumatt Sam	Sam Shumatt				
- 6	Natalie +86- 18938945856		sales15@shumatt.com	Shumatt Natalie	Lin Natalie				
7	Ada	+86-1342286353	sales5@shumatt.com	Shumatt Ada	Ada Shumatt				
8	Hison Li	+86-18318811871	web@shumatt.com	Hison Li	Hison Li				
9	Mecca	+86-18938948618	sales11@shumatt.com	Shumatt Mecca	Shumatt Mecca				
10	ST Eric S	+86 18319033618	sales3@shumatt.com	Start, Start,	S1400 S140				
11	Wayne ( Joaquín en español )	+86-13316959821	wayne@shumatt.com	shumattwayne	Wayne Shumatt				
12	Sylvia	+86 18312499884	sales6@shumatt.com	1000 m	. 0.00				
ST	Visit http://shumatt.com to obtain the latest information of sales-men								
		PS: Shumatt's sales-men's e	mails are all end with @shumatt.com	1					

# 6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds or videos, etc.) provided in "0445110181 *Injector CRI1-13 Technical File*" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "0445110181 *Injector CRI1-13 Technical File*" in any way. At the same time, any conditions to spread, re-post, display the contents of "0445110181 *InjectorCRI1-13Technical File*" should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "0445110181 *Injector CRI1-13 Technical File*" will violate the "Copyright Law of the People's Republic of China" and other laws and regulations and the provisions of relevant international conventions.

Mob/WhatsApp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>