

SHUMMIT

0445120397 Injector CRIN2-16-BL Technical File SHUMAT SHUMATT SAUMA SKU: G1W20445120397 SKU: Z1L30445120397 SHUMPT SHAIMAT SHAMMET SHAMMETT SHAMMETT



st.



Mob/WhatsApp: +86 13410541523 Email: ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133 Website: www.shumatt.com

### 0445120399 Injector CRIN2-16-BL Technical File

#### 1.4. 0445120399 Injector's Parameter ...... 5 1.8. 0445120399 Injector's Packing List and Package Size ......7 2.4. 0445120399 Injector 's Reasons for Not Working Normally ...... 10 2.5. 0445120399 Injector 's Causes of Damage...... 11 3.2. 0445120399 Injector's Main Sales Markets......12 3.5. 0445120399 Injector's Lead time ......12 5.2. Sales-men's Contact Information......15

SKYDDAL SK

. THERE THE

# 0445120399 Injector CRIN2-16-BL Technical File

ANSE.

-18 C

## 1. 0445120399 Injector's Introduction

#### 1.1.0445120399 Injector's Basic Information

ः <sup>स्थि</sup> ार्धि	e	S 10	China n	nade new	/ high qu	uality die	sel inject	or 04451	.20399 fi	uel injecto	or	30
SKL	J					G1W20	4451203	99				
1990	1. 18 C .	~ C.S	1. C. C.	. A.C.	100 C	all the	A.C.	1. Carlo	. 650		1. C. S. S.	1

## 1.2.0445120399 Injector's Common Part Number

(1)	njector	''s Excha	nge In	torm	atio	n	 
	1. K	-13. A			-		

all all	Injecto	or Part Nur	nber	Re-manu	ifactured P	art Number	It was the	1.00
- 90° - 90° - 1	SV SV.	201	36.2 30		30	30. 30.		- 58%
	04	45120399	1		1			
The The	and the second	al said	S	100	all is	Stand Stand	and the second	(š
All All .	49° - 49°	130	All a	J	10	All A	3°° - 23 <sup>90</sup>	de

#### (2) Injector's Application Information

Injector Part Number	CATERPILLAR	PERKINS	/	/
0445120399		- 1	a d a	
0 445 120 518	4493315	T417829	an an an a	an stan at
	/	/	/	/
and the second of the	and all all all all all all all all all al	and water water	and and a start a	and and a

(3) Injector's Part Number Common Writing 0445120399, 0 445 120 399, 0445 120 399, 0445120 399, 0 445120399, 0 445120 399, 0445120518, 0 445 120 518, 0445 120 518, 0445120 518, 0 445120518, 0 445120 518, 0445120400, 0 445 120 400, 0445 120 400, 0445120 400, 0 445120400, 0 445120 400

Ş. st<sup>ys</sup> 3<sup>03</sup> 3<sup>3,3</sup>  $\otimes^{[0]}$  $\leq \lambda^{(0)}$ and Ca di <sup>66</sup> airtí.

SHUMMI

**1.3.** 0445120399 Injector's Matching Information

<b>1.3.</b> 0445120399 <b>I</b>	njector's I	Matching Inform	nation	The The	1 mil	1	St	The The N			
Vehicle Brand	Series	Car Model	Engine Model	Production Date	Power (KW)	Horse Power	Emission Standards	Manufacturer	Emissions (L)	Cylinder	Power Source (V)
PERKINS	1100 🛸	AUTORY SHUTTERY S	1104D-E44T	09/2014 -	68-74.5	92-101	SHUMA	PERKINS	4.4	4	24
PERKINS	1100 🤿	ANDALL SHADDALL	1104D-E44TA	09/2014 -	74.5-106	101-144	SAUMA	PERKINS	4.4	4	24
PERKINS	1100	AUNIFITI	1106D-E66TA	09/2014 -	SHALMATT	UNIPITI SIRIN	art stant	PERKINS	6.6	6	12



Mob/WhatsApp: +86 13410541523 Tel: +8675523215133 Website: www.shumatt.com Email: ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

4 / 15

#### 1.4. 0445120399 Injector's Parameter

20

Adaptation System: Common Rail System Injector Series: 120 Series Parameter Performance: CRIN2-16-BL Matching Accessories: Gasket F 00R J01 453 (15.1\*7.7\*1.5cm Without Groove) Injector Type: Electromagnetic Injector Support System Maximum Pressure: 1,600 Vehicle Configuration Information: PERKINS/CATERPILLAR

TIM The 1.5. 0445120399 Injector's Specifications and Dimensions **Injector Size:** 21 cm\*7 cm \*6 cm = 882cm<sup>3</sup> (L\*W\*H=V) Injector Net Weight: 0.45kg Gross Weight: 0.6kg Injector Quality: China Made Brand New Injector **Package Size:** 28cm\*7 cm \*7 cm = 1372 cm<sup>3</sup> Injector Type: Diesel Common Rail Injector MOQ: 4 Pieces

100

170

#### 1.6. 0445120399 Injector's Quality Control

#### (1) Injector Testing

All injector spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

2

#### (2) Injector Assembling

And the quality control of the injector production and installation process, our company strictly follows the standard product installation data and product installation steps to install, such as injector stroke test, injector solenoid valve tightening torque, injector nozzle tightening torque,

#### (3) Injector Inspection

The factory inspection of the injector is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same fuel injector for a total of no less than three times for factory inspection, and the fuel injector installation and test environment are progressed in dust-free workshop.

#### 1.7. 0445120399 Injector's Customized Service

(1) Injector's Customized Service: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, injector internal packaging, injector external packaging and labels customized, etc.









Injector nozzle engraving

Injector solenoid valve engraving

#### Injector box and label

#### (2) Injector's Customized Service Requirements:

The purchased of customized injector are not less than 10 pieces.


Customized injector packages no less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

A Once the customized fuel injector is sold, it cannot be returned or exchanged if there is no quality

Mob/WhatsApp: +86 13410541523 Email: ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133 Website: www.shumatt.com



Mob/WhatsApp: +86 13410541523 Email: <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd Tel: +8675523215133 Website: www.shumatt.com

#### **1.8.** 0445120399 Injector's Packing List and Package Size

(1) Injector Spare Parts List

(1) Injec	tor Spare Parts List		5 5 5 S
No.	and the set	AN 12 AN 14	30 AM A
antimage at			CONT SHADN O SHADN'T SH
Name	Fuel Injector	O-Ring	Gasket F 00V C17 503
Description	Fuel injector part number: 0445120518	Ensure to meet the standard of the sealing performance between the injector and the engine	Made of brass, used to ensure the tight fit between the injector cap end and the engine
- 3 <sup>10</sup> No 31	4	st <sup>er</sup> st <sup>er</sup> 5 st <sup>er</sup> st <sup>er</sup>	96 96 9
Stellinge St		st <sup>el</sup> St <sup>el</sup>	
	an an an	ster stor stor sto	<u> </u>
Name	Nozzle Protective Cover Cap	Injector Inlet Hole Protective Cover	Injector Oil Return Hole Protective Cover
Description	Protect nozzle holes from being polluted and blocked	Protect the injector inlet hole from being polluted and blocked	Protect the injector oil return hole from being polluted and blocked
3 No. 3	5 <b>7</b> 5	8 8 8 8	87 87 87 87 8
and the second s		STR.B	
all the all	It all all all	all all all all	
<sup>on</sup> Name	VCI Anti-rust Bag	Bubble Bag	Injector Packing Box
Description	Prevent fuel injector from rusting	Prevent the injector from being damaged by external forces	Place injector and injector accessories
<ul> <li>a. 00024</li> </ul>	CONTRACT AND	A 1000 A 1000 A 1000 A 1	TOD - 1000 - 1000 - 1000 - 1000 - 1000


A Minors are forbidden to use the fuel injector assembly, O-ring, gasket, nozzle protective cover, fuel injector house protective cover, solenoid valve protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.

▲ O-ring and gasket are disposable installation accessories, and need to be replaced for re-installation.

▲ The nozzle protective cover, the injector house protective cover, and the solenoid valve protective cover are recyclable accessories that can be reused.

▲ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

• The injector and the installation parts should be coated with appropriate sealing oil during installation.



#### 1.9. 0445120399 Injector's Testing Standard and Certificate

UMATT

We can provide the factory quality inspection test report of each injector to ensure that each injector delivered meets the engine performance indicators.

BOTEN	Mi	武报告	4.05.201	9 10:42:09		100				100°	10111	1000	
建全业:				(H)		A	а .					T SHLEET	
E.		sta :			5181205	StREET	Stane.	R SPURA	T STUDIO	C. SHATTE	T SALES	1 . dil	ē,
		2周人:			Star -	Star -	-300	Store -	- S3 <sup>447</sup>	- 198 <sup>0 - 1</sup>	Star.	- 98 <sup>907</sup>	
815.		cie#12					-				-	_	
		0.000.000											
		6户姓名:		8	100	Den sak	E - sali	9 - Lafe	$\mathbb{C}^{+} \rightarrow \mathbb{C}^{+}$	C	C	C. Star	5
的迷:					5272.525	ST. SPERIO	S. S	STRUES	CT. STATERS	- A. 100	C. SALES	5 23.25	
名称:	10 10 pr				Sec. 1	- 19 miles	200	24 A	Sec.	Sec.	Dort.	Sec.	
零件号:													
IA.					5171.575	ET STRUME	S. Status	a State	C. SPURA	C. SPATON	5. 519,575	1 519-503	đ
P1.	**********			3				1	1	1. a. 1977			Î
18179 : COSOC	他第 00-6511	则结果			927°	- 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 1997 - 199	- States	- 98° -	977 °	5777	- 570° -	- 92 C	
NÀ X An TEST: 32	1998-1998-1998-1998-1998-1998-1998-1998	Réak OPB	800 × 10										
de ut		357	414215	*							-1	<i></i>	
ARM: 3,8 MC 201		0	·····		12	S	S	9	9	9	9	0	Я.
. 38.4		0	·····b·····	4	-330°	57 5892,0757	ST STRUME	r. Strange	and the second	1997 -	C. Statist	5 373.575	1
2 HU 5 A2		63 63		1	2012	200	200	543	244	341	201	201	
				18									
					519.5715	57 5192000	6	di se	d	di w	Charles and	5 39.50%	¢
					1.250	·					578-5787		1
					22	62	22	40.0	24	200	25	200	
[]a2 []a5 []a 修館 重沙!	en _es _es _es _es	· 2007015											
										. e	6	6	
150	- 2017	÷	and the second second		C	5 - La	5	1	r	6 . d	Star and Star	and the second sec	ж.

#### 1.10. 0445120399 Injector's Warranty Instructions

#### (1) . Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the injector inspection equipment when the injector is abnormal during use as evidence to feed back to the salesman. Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

#### (2) . Injector Warranty Coverage

Within 15 days after customer receives the **0445120399**injector, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the **0445120399**injector has performance problems during the warranty period (3 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

## (3) . Injector Out of Warranty Coverage

The warranty period has expired.

Injector failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.

Customer disassembles or repairs the injector personally resulting in damage to the injector.

Injector damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).

Injector failure or injector damage caused by non-injector design, technology, manufacturing, quality and other issues.

Injector failure due to system pressure exceeding system approved pressure.

Injector failure caused by system voltage exceeding approved voltage.

Injector failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.

Injector failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

Injector failure caused by not following the installation angle specified in the vehicle engine maintenance manual.

Injector failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.

Injector failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.

Injector failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.

Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the fuel injector connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

#### 1.11. 0445120399 Injector's Manufacturer

 $\mathcal{S}^{(1)}$ 

 $c \delta^{B^{T}}$ 


Injector's manufacturer: Shenzhen Shumatt Technology Co., Ltd

#### 2. 0445120399 Injector Technical Support

#### 2 1 0 4 4 5 1 2 0 2 0 0 Latin stands David New Law Law Law

#### 2.1. 0445120399 Injector's Part Number Location


1) E.g.: The injector part number see as follows



#### 2.2. 0445120399 Injector's Application Scenarios

Common rail system is an oil supply method refers to the diesel oil from the fuel tank sucked out by the gear pump through the oil-water separator and the gear pump to diesel fine filter, high-pressure pump, common rail pipe, and fuel injector, all together with the closed-loop fuel supply system composed of sensors and ECU that completely separates the generation of injection pressure and the injection process





No.	Name	No.	Name	No.	Name	No.	Name
1	Tank	5	Common Rail Pressure Sensor	9	Engine Crankshaft Sensor	А	High Pressure Oil Circuit
ST2/081	Diesel Filter	6.0	Common Rail Pipe	10	Camshaft Sensor	¢ <sup>6</sup> B ₹	Low Pressure Oil Circuit
3	High-Pressure Pump	7	Injector	11	ECU Electronic Control Unit	_	
4,00	Fuel Gear Pump	8	Accelerator Pedal	. All	all all a	all is	at at a

#### 2.3. 0445120399 Injector's Installation

#### (1) .0445120399 Injector's Installation Precautions :

▲ The replacement of the fuel injector must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual,

A Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector, the fitting clearance of the fuel injector connection, the installation angle and tightening torque of the injector, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the injector.

▲ When installing the fuel injector on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the fuel injector, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

Before installing, check whether the fuel injector nozzle gasket has been replaced and installed on the fuel injector.

▲ When installing the fuel injector, apply lubricant between the fuel injector, fuel nozzle sealing gasket and O-ring.

▲ Without replacing new gasket can lead to: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the fuel injector and nozzle to break and cause damage to the engine.

▲ When installing the injector on the engine, please carefully check the components related to the installation of the injector, such as the injector pressure plate, screw, injector rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.

▲ It is forbidden to operate the bare injector for a long time in an environment with serious dust pollution and corrosion to iron products.

• It is forbidden to operate the bare injector for a long time in a strong magnetic field environment.

#### 2.4. 0445120399 Injector 's Reasons for Not Working Normally

(1) There is air in the oil circuit of the engine fuel system.

(2) Vehicle oil pump oil supply system is not normal.

(3) Engine common rail system oil leakage or pressure limiting valve damage.

(4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the fuel " States, States, States, States, Strates, Strates, Strates, Strates, injector of the vehicle.

(5) The long-term placement of the injector causes the anti-rust oil to solidify, and the internal al l components are stuck or the oil holes are blocked. - The The Par 65

Before installing, carefully check whether other components in the common rail system except the fuelinjector is damaged so as to prevent the fuel injector from not working properly after being replaced. 15%

SPACE **2.5.** 0445120399 **Injector 's Causes of Damage** (1) Didn't operate properly according to the second SPLEET 570,500 51<sup>0,000</sup> SAST (1) Didn't operate properly according to engine maintenance manual during disassembly or installation, 124 18<sup>15</sup> 18 St. 1000 and the 1997 resulting in damage to the injector. 19<sup>5</sup> -

(2) The fuel oil used for the vehicle does not meet the standard cause damage to the injector, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities UNERT CERT. and S. ATTEN L NEW COL ai<sup>nth</sup> exceed the standard, etc.

(3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause NUT OF . 1787 C.S. NS REAL AD THE C 25087 damage to the injector.  $\omega^{(2^n)}$ 

(4) The abrasion of the oil pump produces iron powder and aluminum powder enter the fuel injector and cause damage to the fuel injector.

(5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the fuel injector and causing damage to the fuel injector.

(6) The fuel injector is damaged due to replacement or adjustment of the relevant parts of the fuel injector. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the injector fails to meet the original 1000 15 15 15 B a Title Title Title Title Title Title standard. 17. S

(7) The engine is overheated and overloaded for a long time working results in damage to the fuel injector.

(8) The injector will be damaged naturally at the end of its working life. 100

(9) The injector is magnetized (injector parts' magnetic exceeded) causing the injector to not work properly.

A Before replacing the fuel injector, please check the engine parts carefully according to the engine maintenance manual to avoid the fuel injector being damaged again after replacement.

#### 2.6. 0445120399 Injector's Technical Support Obtaining Methods

(1) Injector Technical File, visit <u>http://shumatt.com</u> to get the technical file.

(2) Injector Technical Videos

Facebook: Visit https://www.facebook.com/hison.li to get the technical videos, constantly follow can get more information.

YouTube: https://www.youtube.com/channel/UCByvYBx7ViV mAfxh Hu-aw to get the technical videos, - 310<sup>00</sup>  $S^{\mathbb{N}^{|\mathcal{S}|}}$ -Sh<sup>ift</sup> constantly follow can get more information. -33<sup>-54</sup> al an  $ab^{(0)}$ 

**Shumatt:** Visit <u>http://shumatt.com</u> to get the technical videos.

(3) Injector Information Query Software

100 1997  $e^{i \frac{1}{2} \sum_{i=1}^{n}}$  $e^{i \frac{1}{2}}$ TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial

- 977

15

(4) Search The fuel injector test data through TruckBook Parts EPC APP.

3. 0445120399 Injector's Purchase and Delivery

. "The and the 

#### 3.1. 0445120399 Injector's Purchase Payment Terms

#### **Payment Terms:** T/T, PayPal, Alipay, WeChat

33<sup>01</sup>

. 6 S<sup>EN</sup> .

. n. 1974

Please contact our salesmen for specific payment information.

#### 3.2. 0445120399 Injector's Main Sales Markets

Injector main sales markets: Asia, Europe, North America, South America, Africa etc. Share

#### $M^{22}$ 3.3. 0445120399 Injector's Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, North Contraction invoice, packing list, bill of lading, insurance policy, certificate of origin, etc. AND C ad a fair

16 (PA

10<sup>06</sup>

SHIP

SALT

#### 3.4. 0445120399 Injector's Shipping Ways

Destination in China areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China's areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by A.S. 53.<sup>303</sup> and the SH150 customers. 38°

#### 3.5. 0445120399 Injector's Lead time

Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases).

#### 3.6. 0445120399 Injector's Logistics Time for Destination Out of China's Areas **DHL Logistics Time:**

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Davs	7 Davs	8 Davs	8 Davs	8-12 Days	7-10 Days

#### UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	ик 🖇	5-7 Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy Street	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	S Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	The The The	and an	S. St. St.	The The

The logistics time is for reference only subjects are according to the actual arrival.

#### 3.7.0445120399 Injector's Packing

Mob/WhatsApp: +86 13410541523 Email: ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd


**Domestic express packaging:** Usually wrapped in waterproof scotch tape, such as picture No.2. International express packaging: Wrapped with waterproof yellow tape After wrapping the black -Str. M STRATE 51.50 39.<sup>50</sup>  $S^{\mathbb{R}^{|\mathcal{G}|}}$  $\otimes^{\mathbb{N}^{(2)}}$ protective film, such as picture No. 3.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 4,  $\mathfrak{S}^{[0]}$ Also, the products can be packaged according to customers' requirements.

• The packing tray is made of plastic and can be recycled.

Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non A SIBJER.  $\mathcal{S}^{h, \mathcal{V}}$ degradable materials, please dispose of them properly.

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and and the second No. white wrapping protective film to avoid personal injury.



Domestic express packaging: International express packaging: Wrapped by Transparent tape Wrapped with yellow tape after wrapping black protective film





Pic No. 4

Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

#### 4. 0445120399 Injector's Storage Standard

#### (1) Choose a suitable storage place 18 C

 $d\tilde{V}^{0}$ The warehouse and cargo yard where the fuel injector is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area

#### drv.

#### (2) Strict requirements of warehousing

Strict inspections should be carried out when the fuel injectors are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injectors must be protected from damage.

#### (3) Keep the warehouse dry and preventing moisture

The relative humidity is usually below 70% for the fuel injectors placed in the room, and the corrosion 150 of the fuel injectors is significantly reduced. The The The The 100

Injectors must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content. 18<sup>13</sup> 10

#### (4) Stack Properly

1853 1. 18 May 10 188<sup>35</sup> and the States -After the injector is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector from rainwater and humid air, so the warehouse window should be checked 2.173871 179932 in time to avoid rainwater entering the warehouse

If the fuel injector package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

**A** It is forbidden to leave the injector exposed in the air for a long time.

▲ It is forbidden to store acid, alkali, salt and other substances together with the injector.

A The unpacked fuel injector must be rust-proof during secondary storage. 5. Company

Information

a C

5.1. Company Introduction Chinese Name: 深圳市舒马特科技有限公司 English Name: Shenzhen Shumatt Technology Co., Ltd **Mob Phone/WeChat:** +86-13410541523 HK Telephone: +852-67653519 Telephone: +86-755-23215133 Email: ruby@shumatt.com

Website: www.shumatt.net

Mos/WffigeApp?#80913410541523 Email: ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Room 428-430, Building B, Huafeng Zhigu Technology Industrial Park, Exit B, Fuyong Metro Station, Bao'an District, Shenzhen, China's Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: <u>1.10.0445120518</u> Injector Warranty Instructions)

No.	Name	WeChat/ WhatsApp	Email	Facebook	YouTube
1,000	Ruby	+86-13410541523	ruby@shumatt.com	Hison Li	Hison Li
2	lvy	+86-18025309821	sales@shumatt.com	Ivy Shumatt	Shumatt IVY
3	Rebecça	+86-18025349821	sales01@shumatt.com	Rebecca SHUMATT	SHUMATT Rebecca
4	Janny	+86-18028749821	sales02@shumatt.com	Janny shumatt	Janny Shumatt
5	Sam	+86-13316859821	Sales8@shumatt.com	Shumatt Sam	Sam Shumatt
6	Natalie	+86- 18938945856	sales15@shumatt.com	Shumatt Natalie	Lin Natalie
76	Ada	+86-1342286353	sales5@shumatt.com	Shumatt Ada	Ada Shumatt
8	Hison Li	+86-18318811871	web@shumatt.com	Hison Li	Hison Li
9	Mecca	+86-18938948618	sales11@shumatt.com	Shumatt Mecca	Shumatt Mecca
10	Eric	+86 18319033618	sales3@shumatt.com		5 5
$1_{[0]}(0)^{(j)}$	Wayne ( Joaquín en español )	+86-13316959821	wayne@shumatt.com	shumattwayne	Wayne Shumatt
12	Sylvia	+86 18312499884	sales6@shumatt.com		
	8 5 5	Visit http://shumatt.com to ot	ptain the latest information of salesmo	en 🦯	5 5
	10 m m	PS: Shumatt's sales-men's e	mails are all end with @shumatt.com	and and	1

#### 5.2. Sales-men's Contact Information

#### 6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds or videos, etc.) provided in "**0445120399** *Injector CRIN2-16-BL Technical File*" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "**0445120399** *Injector CRIN2-16-BL Technical File*" in any way. At the same time, any conditions to spread, re-post, display the contents of "**0445120399** *Injector CRIN2-16-BL Technical File*" in any way. At the same time, any conditions to spread, re-post, display the contents of "**0445120399** *Injector CRIN2-16-BL Technical File*" should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "**0445120399** *Injector CRIN2-16-BL Technical File*" will violate the "*Copyright Law of the People's Republic of China*" and other laws and regulations and the provisions of relevant international conventions.

